


WSM

WORKSHOP MANUAL
TRACTOR

**B2630HSD, B3030HSD,
B3030HSDC**

Kubota




Crankshaft Alignment

1. Support the crankshaft with V blocks on the surface plate at both end journals.
2. Set a dial indicator with its tip on the intermediate journal.
3. Measure the crankshaft alignment.
4. If the measurement exceeds the allowable limit, replace the crankshaft.

Crankshaft alignment	Allowable limit	0.02 mm 0.0008 in.
----------------------	-----------------	-----------------------

W1099507




Oil Clearance between Crankpin and Crankpin Bearing

1. Clean the crankpin and crankpin bearing.
2. Put a strip of plastigauge on the center of the crankpin.
3. Install the connecting rod cap and tighten the connecting rod screws to the specified torque, and remove the cap again.
4. Measure the amount of the flattening with the scale, and get the oil clearance.
5. If the oil clearance exceeds the allowable limit, replace the crankpin bearing.
6. If the same size bearing is useless because of the crankpin wear, replace it with an undersize one referring to the table and figure.

NOTE

- Never insert the plastigauge into the crankpin oil hole.
- Be sure not to move the crankshaft while the connecting rod screws are tightened.



Oil clearance between crankpin and crankpin bearing	Factory spec.	0.029 to 0.091 mm 0.0011 to 0.0036 in.
	Allowable limit	0.20 mm 0.0079 in.

Crankpin O.D.	Factory spec.	39.959 to 39.975 mm 1.5732 to 1.5738 in.
Crankpin bearing I.D.	Factory spec.	40.040 to 40.050 mm 1.5764 to 1.5767 in.

(Reference)

- Undersize dimensions of crankpin

Undersize	0.2 mm 0.008 in.	0.4 mm 0.016 in.
Dimension A	2.8 to 3.2 mm radius 0.1102 to 0.1260 in. radius	2.8 to 3.2 mm radius 0.1102 to 0.1260 in. radius
*Dimension B	1.0 to 1.5 mm relief 0.0394 to 0.0591 in. relief	1.0 to 1.5 mm relief 0.0394 to 0.0591 in. relief
Dimension C	39.759 to 39.775 mm dia. 1.5653 to 1.5659 in. dia.	39.559 to 39.575 mm dia. 1.5574 to 1.5581 in. dia.

(R-S)


The crankpin must be fine-finished to higher than $\nabla\nabla\nabla\nabla$
 *Holes to be de-burred and edges rounded with 1.0 to 1.5 mm
 (0.0394 to 0.0591 in.) relief.

W10331060


(3) PTO Clutch Case




3TBAAAG3P112A



3TBAAAG3P113A



3TBAAAG3P114A



3TBAAAG3P115A

Separating Transmission case and PTO Clutch Case

1. Remove the transmission case mounting bolts.
2. Separate the transmission case (1) from the differential case (2).
3. Remove the PTO brake plate 4 mounting bolt (4).

(When reassembling)

- Install the PTO brake plate 4 (5) to the transmission case groove (7) securely as shown in the picture.
- Place the PTO brake plate 2 (6) between **A** and **B**.

Tightening torque	Transmission case mounting bolt (M10) and nut	39.3 to 44.1 N·m 4.0 to 4.5 kgf·m 29.0 to 32.5 lbf·ft
	Hydraulic cylinder mounting bolt (M10) and nut	39.3 to 44.1 N·m 4.0 to 4.5 kgf·m 29.0 to 32.5 lbf·ft

- (1) Transmission Case
 - (2) Differential Case
 - (3) PTO Clutch Case
 - (4) PTO Brake Plate 4 Mounting Bolt
 - (5) PTO Brake Plate 4
 - (6) PTO Brake Plate 2
 - (7) Transmission Case Groove
- A : Position**
B : Position

W1095767

SERVICING

CONTENTS

1. TROUBLESHOOTING	5-S1
2. SERVICING SPECIFICATIONS	5-S2
3. TIGHTENING TORQUES	5-S3
4. CHECKING, DISASSEMBLING AND SERVICING.....	5-S4
[1] CHECKING AND ADJUSTING	5-S4
[2] DISASSEMBLING AND ASSEMBLING.....	5-S5
(1) Separating Front Axle Assembly.....	5-S5
(2) Disassembling Front Assembling.....	5-S7
[3] SERVICING	5-S13

machinecatalogic.com

Full Version Available

Kubota B3030HSD Tractor Workshop Manual

This is a short preview. The complete manual contains all chapters, wiring diagrams, torque specifications and full service procedures.

VIEW THE FULL MANUAL

<https://machinecatalogic.com/kubota-b3030hsd-tractor-workshop-manual/>