


WSM


WORKSHOP MANUAL

F2260, F2560(E), F3060, F3560

Кубота



11790F10520



11790F10530

Main Bearing Case Assembly

1. Remove the two main bearing case screws 1, and remove the main bearing case assembly, being careful with the thrust bearing and crankshaft bearing 2.
2. Remove the main bearing case assembly 1 and 2 as above. (D1005-EFM and D1105-EFM)
3. Remove the main bearing case assembly 1, 2 and 3 as above. (V1305-EFM and V1505-EFM)

(When reassembling)

- Clean the oil passage in the main bearing case.
- Apply clean engine oil on the bearings.
- Install the main bearing case assemblies in the original positions. Since diameters of main bearing case vary, install them in order of makings [A, B (D1005-EFM and D1105-EFM) / A, B, C (V1305-EFM and V1505-EFM)] from the gear case side.
- Match the alignment numbers (1) on the main bearing case.
- When installing the main bearing case 1, 2, and 3, face the mark "FLYWHEEL" to the flywheel.
- Install the thrust bearing with its oil groove facing outward.
- Confirm that the main bearing case moves smoothly after tightening the main bearing case screw 1 to the specified torque.


Tightening torque	Main bearing case screw 1	29.4 to 34.3 N·m 3.0 to 3.5 kgf·m 21.7 to 25.3 ft·lbs
-------------------	---------------------------	---

(1) Alignment Number


11900S10250

SERVICING

(1) Cylinder Head and Valves



00000F10010



00000F10020

Cylinder Head Surface Flatness


1. Clean the cylinder head surface.
2. Place a straightedge on the cylinder head's four sides and two diagonal as shown in the figure.
3. Measure the clearance with a feeler gauge.
4. If the measurement exceeds the allowable limit, correct it with a surface grinder.

■ IMPORTANT

- Do not place the straightedge on the combustion chamber.
- Be sure to check the valve recessing after correcting.

Cylinder head surface flatness	Allowable limit	0.05 mm 0.0020 in.
--------------------------------	-----------------	-----------------------

00000S10010



11900F30110

Drive Shaft

1. Unscrew the drive shaft mounting screws (2).
2. Remove the drive shaft (1) from HST pump shaft.

(When reassembling)

■ **NOTE**

- Apply grease to the splines on the drive shaft and HST pump shaft.

■ **IMPORTANT**


- Be sure to tighten the drive shaft mounting screws (2) to the specified torque.

Tightening torque	Drive shaft mounting screw	27.5 to 29.4 N·m 2.8 to 3.0 kgf·m 20.3 to 21.6 ft-lbs
-------------------	----------------------------	---

(1) Drive Shaft

(2) Drive Shaft Mounting Screw

11900S30100



11900P30080


Separating Transmission and Front Axle

1. Support the rear end of the transmission and frame with a disassembly stand.
2. Unscrew the transmission mounting screws, and separate the transmission and front axle.

(When reassembling)

■ **NOTE**

- Apply liquid lock (Three Bond 1324 or its equivalent) to the transmission mounting screws.
- Screw in the reamer screws, first.
- Mount the stay (1) between the side frame (2) and main frame (3).



11902F30010

Tightening torque	Transmission mounting screw (M12)	62.8 to 72.5 N·m 6.4 to 7.4 kgf·m 46.3 to 53.5 ft-lbs
	Stay mounting screw (4), (5)	77.6 to 90.2 N·m 8.0 to 9.0 kgf·m 57.1 to 66.5 ft-lbs

(1) Stay

(2) Side Frame

(3) Main Frame

(4) Stay Mounting Screw

(5) Screw

11902S30110

SERVICING SPECIFICATIONS

Item		Factory Specification	Allowable Limit
Adjusting Screw Length		Approx. 15.0 mm Approx. 0.59 in.	15 to 20 mm 0.59 to 0.79 in.
Check and High Relief Pressure		27.9 MPa 285 kgf/cm ² 4056 psi	—
Charge Pressure		400 to 600 kPa 4.1 to 6.1 kgf/cm ² 58 to 87 psi	—
Piston to Bore (HST)	Clearance	0.02 mm 0.0008 in.	0.04 mm 0.0016 in.
Piston Slipper (HST)	Thickness	3.00 mm 0.118 in.	2.90 mm 0.1142 in.

11901S30590

TIGHTENING TORQUES

Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts : See page G-9.)

Item	N·m	kgf·m	ft·lbs
Oil strainer	98.1 to 137.2	10.0 to 14.0	72.4 to 101.2
ROPS mounting screw	77.5 to 90.2	7.9 to 9.2	57.2 to 66.5
Ø10 mm (0.394 in.) pipe mounting screw	39.3 to 49.0	4.0 to 5.0	28.9 to 36.1
Ø12 mm (0.472 in.) pipe mounting screw	54.0 to 63.7	5.5 to 6.5	39.8 to 47.0
Power steering hose 1 and 2	24.6 to 29.4	2.5 to 3.0	18.1 to 21.6
Power steering hose P	24.6 to 29.4	2.5 to 3.0	18.1 to 21.6
Drive shaft mounting screw	27.5 to 29.4	2.8 to 3.0	20.3 to 21.6
Transmission mounting screw (M12)	62.8 to 72.5	6.4 to 7.4	46.3 to 53.5
Frame stay mounting screw	77.6 to 90.2	8.0 to 9.2	57.1 to 66.5
Side frame mounting screw and nut	62.8 to 72.5	6.4 to 7.4	46.3 to 53.5
PTO pipe mounting screw	54.0 to 63.7	5.5 to 6.5	39.8 to 47.0
HST mounting screw (M8)	23.6 to 27.4	2.4 to 2.8	17.4 to 20.2
HST mounting screw (M10)	39.3 to 44.1	4.0 to 4.5	29.0 to 32.5
Hex. socket head screw	49.0 to 58.8	5.0 to 6.0	36.2 to 43.4
Check and high pressure relief valve plug	58.8 to 107.9	6.0 to 11.0	43.4 to 79.6

11901S30600

HYDRAULIC CYLINDER

Item		Factory Specification	Allowable Limit
Hydraulic Cylinder	I.D.	70.05 to 70.10 mm 2.7579 to 2.7598 in.	70.15 mm 2.7618 in.
Hydraulic Arm Shaft to Bushing	Clearance (Left and Right)	0.020 to 0.110 mm 0.0008 to 0.0043 in.	0.30 mm 0.0118 in.
Hydraulic Arm Shaft	O.D. (Left)	37.925 to 37.950 mm 1.4931 to 1.4941 in.	—
	O.D. (Right)	33.925 to 33.950 mm 1.3356 to 1.3366 in.	—
Bushing	I.D. (Left)	37.970 to 38.035 mm 1.4949 to 1.4974 in.	—
	I.D. (Right)	33.970 to 34.035 mm 1.3374 to 1.3400 in.	—

PTO CLUTCH

PTO Charge Pressure Condition • Engine Speed Maximum • Oil Temperature 50 °C 122 °F	Setting Pressure	785 to 1078 kPa 8.0 to 11.0 kgf/cm ² 114 to 156 psi	—
PTO Brake Plate	Thickness	4.35 to 4.65 mm 0.1713 to 0.1830 in.	4.25 mm 0.1673 in.
PTO Brake Disc	Thickness	3.65 to 3.95 mm 0.1437 to 0.1555 in.	3.30 mm 0.1299 in.
Pressure Plate	Thickness	1.95 to 2.05 mm 0.0768 to 0.0807 in.	1.80 mm 0.0709 in.
Clutch Disc	Thickness	1.90 to 2.10 mm 0.7480 to 0.0827 in.	1.60 mm 0.0630 in.
Steel Plate	Thickness	0.95 to 1.05 mm 0.0374 to 0.0413 in.	0.80 mm 0.0315 in.

11900S80030

TIGHTENING TORQUES

Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts : See page G-9.)

Item	N-m	kgf-m	ft-lbs
Fuel cut off solenoid mounting screw	9.80 to 11.2	1.00 to 1.15	7.24 to 8.32
Flow priority valve mounting screw	17.7 to 20.6	1.8 to 2.1	13.0 to 15.2
Delivery hose mounting nut	24.6 to 29.4	2.5 to 3.0	14.5 to 21.6
Hydraulic pump mounting screw and nut	23.6 to 27.4	2.4 to 2.8	17.4 to 20.2
Cover mounting screw	39.2 to 44.1	4.0 to 4.5	28.9 to 32.5
Hydraulic cylinder assembly mounting screw and nut	39.2 to 44.1	4.0 to 4.5	28.9 to 32.5
Control valve mounting screw	23.6 to 27.4	2.4 to 2.8	17.4 to 20.2
Relief valve plug	49.0 to 68.6	5.0 to 7.0	36.2 to 50.6

11900S80040

Full Version Available

Kubota F2560(E) Front Mower Workshop Manual

This is a short preview. The complete manual contains all chapters, wiring diagrams, torque specifications and full service procedures.

[VIEW THE FULL MANUAL](https://machinecatalogic.com/kubota-f2560-e-front-mower-workshop-manual/)

<https://machinecatalogic.com/kubota-f2560-e-front-mower-workshop-manual/>