

## TO THE READER

This Workshop Manual has been prepared to provide servicing personnel with information on the mechanism, service and maintenance of KUBOTA Tractors L2600 and L3000. It is divided into two parts, "Mechanism" and "Servicing" for each section.

### ■ Mechanism

Information on the construction and function are included. This part should be understood before proceeding with troubleshooting, disassembling and servicing.

### ■ Servicing

Under the heading "General" section comes general precautions, check and maintenance and special tools. Other section, there are troubleshooting, servicing specification lists, checking and adjusting, disassembling and assembling, and servicing which cover procedures, precautions, factory specifications and allowable limits.


All information, illustrations and specifications contained in this manual are based on the latest production information available at the time of publication.

The right is reserved to make changes in all information at any time without notice.

March 2000

© KUBOTA Corporation 2000

12530Z00010




**Valve Seating**


1. Coat the valve face lightly with prussian blue and put the valve on its seat to check the contact.
2. If the valve does not seat all the way around the valve seat or the valve contact is less than 70 %, correct the valve seating as follows.
3. If the valve contact does not comply with the reference value, replace the valve or correct the contact of valve seating.

- (1) Correct  
(2) Incorrect

- (3) Incorrect



11790S10230



**Correcting Valve and Valve Seat**

**NOTE**


- Before correcting the valve and seat, check the valve stem and the I.D. of the valve guide section, and repair them if necessary.
- After correcting the valve seat, be sure to check the valve recessing.

**1) Correcting Valve**

1. Correct the valve with a valve refacer.


**2) Correcting Valve Seat**

1. Slightly correct the seat surface with a 1.05 rad. (60°) (intake valve) or 0.79 rad. (45°) (exhaust valve) seat cutter.
2. Resurface the seat surface with a 0.52 rad. (30°) valve seat cutter to intake valve seat and with a 0.26 rad. (15°) valve seat cutter to exhaust valve seat so that the width is close to specified valve seat width (2.12 mm, 0.0835 in.).
3. After resurfacing the seat, inspect for even valve seating, apply a thin film of compound between the valve face and valve seat, and fit them with valve lapping tool.
4. Check the valve seating with prussian blue. The valve seating surface should show good contact all the way around.



- (a) Identical Dimensions  
(b) Valve Seat Width

- (A) Check Contact  
(B) Correct Seat Width  
(C) Check Contact




12530S10370

## TROUBLESHOOTING

Symptom	Probable Cause	Solution	Reference Page
<b>Excessive Transmission Noise</b>	<ul style="list-style-type: none"> <li>• Transmission fluid insufficient</li> <li>• Gear worn or backlash improper</li> <li>• Bearings worn or broken</li> <li>• Shift fork worn</li> <li>• Spline worn</li> <li>• Snap rings on the shaft come off</li> <li>• Spiral bevel pinion staking nut improperly tightened</li> <li>• Improper backlash between spiral bevel pinion and spiral bevel gear</li> <li>• Improper backlash between differential pinion and differential side gear</li> </ul>	Replenish Replace Replace Replace Replace Repair or replace Tighten  Adjust  Adjust	G-15 3-S22, S35 3-S23, S34 3-S22, S35 3-S22, S35 – 3-S29  3-S37  3-S38
<b>Gear Slip Out of Mesh</b>	<ul style="list-style-type: none"> <li>• Shift linkages rusted</li> <li>• Shifter or shift fork worn or damaged</li> <li>• Shift fork interlock ball spring weaken or damaged</li> <li>• Interlock ball fallen</li> <li>• Gears worn or broken</li> </ul>	Repair Replace Replace  Reassemble Replace	– 3-S22, S35 3-S22, S35  3-S11, S16 –
<b>Hard Shifting</b>	<ul style="list-style-type: none"> <li>• Shifter or shift fork worn or damaged</li> <li>• Shift fork bent</li> <li>• Shift linkage rusted</li> <li>• Shaft part of shift arms rusted</li> </ul>	Replace Replace Repair Repair	3-S22, S35 – – –
<b>Gears Clash When Shifting</b>	<ul style="list-style-type: none"> <li>• Clutch does not release</li> <li>• Gears worn or damaged</li> </ul>	Adjust or repair Replace	2-S3 –
<b>Differential Lock Can Not Be Set</b>	<ul style="list-style-type: none"> <li>• Differential lock shift fork damaged</li> <li>• Differential lock shift fork mounting spring pin damaged</li> <li>• Differential lock shifter pin bent or damaged</li> <li>• Differential lock fork shaft bent or damaged</li> </ul>	Replace Replace  Replace Replace	3-S27 3-S27  3-S27 3-S27
<b>Differential Lock Pedal Does Not Return</b>	<ul style="list-style-type: none"> <li>• Differential lock pedal return spring weaken or damaged</li> <li>• Differential lock shifter pin bent or damaged</li> <li>• Differential lock cam bent</li> </ul>	Replace  Replace Replace	–  3-S27 3-S27
<b>Excessive or Unusual Noise at All Time</b>	<ul style="list-style-type: none"> <li>• Improper backlash between spiral bevel pinion and spiral bevel gear</li> <li>• Improper backlash between differential pinion and differential side gear</li> <li>• Bearings worn</li> <li>• Insufficient or improper type of transmission fluid used</li> </ul>	Adjust  Adjust  Replace Replenish or replace	3-S37  3-S38  3-S23, S34 G-9, 15
<b>Noise While Turning</b>	<ul style="list-style-type: none"> <li>• Differential pinions or differential side gears worn or damaged</li> <li>• Differential lock binding (does not disengage)</li> <li>• Bearing worn</li> </ul>	Replace  Replace Replace	3-S32, S34  – 3-S23, S34

12530S30510




**Clearance between Differential Case Bore and Differential Side Gear Boss (L2600)**

1. Measure the bore I.D. of the differential case.
2. Measure the boss O.D. of the differential side gear and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace.

Clearance between differential case bore and differential side gear boss	Factory spec.	0.025 to 0.124 mm 0.00098 to 0.00488 in.
	Allowable limit	0.35 mm 0.0138 in.

Differential case bore I.D.	Factory spec.	38.025 to 38.065 mm 1.49704 to 1.49862 in.
Differential side gear boss O.D.	Factory spec.	37.941 to 38.000 mm 1.49374 to 1.49606 in.

12530S30470



**Clearance between Differential Case Bore (Differential Case Cover Bore) and Differential Side Gear Boss (L3000)**

1. Measure the bore I.D. of the differential case and differential case cover.
2. Measure the differential side gear boss O.D. and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace them.

Clearance between differential case bore and differential side gear boss	Factory spec.	0.050 to 0.151 mm 0.00197 to 0.00594 in.
	Allowable limit	0.35 mm 0.0138 in.

Differential case bore I.D.	Factory spec.	40.500 to 40.562 mm 1.59449 to 1.59693 in.
Differential side gear boss O.D.	Factory spec.	40.411 to 40.450 mm 1.59098 to 1.59252 in.


Clearance between differential case cover bore and differential side gear boss	Factory spec.	0.090 to 0.169 mm 0.00354 to 0.00666 in.
	Allowable limit	0.35 mm 0.0138 in.

Differential case cover bore I.D.	Factory spec.	40.540 to 40.580 mm 1.59606 to 1.59764 in.
Differential side gear boss O.D.	Factory spec.	40.411 to 40.450 mm 1.59098 to 1.59252 in.

12530S30490

### [3] OIL STRAINER

The oil strainer is located at the pump suction line.




12040F80050

This oil strainer (1) is located in the transmission case (2), and ensures a filtration degree of #38-65 mesh.

- (1) Oil Strainer
- (2) Transmission Case

12040M80050

### [4] POSITION CONTROL VALVE



12670F80020

#### ■ Neutral

Pressurized oil flows at the P port, pushes open unload poppet (2) and returns to the transmission case from T1 port.

The oil in the A chamber (a) behind the unload poppet (2) returns to the transmission case through the clearance between spool (3) and valve body (4). The oil in the hydraulic cylinder does not flow out because the circuit is cut off by the actions of poppet 1 (1) and poppet 2 (5).

This allows the implement to be kept at a steady height.

- (1) Poppet 1
- (2) Unload Poppet
- (3) Spool
- (4) Valve Body
- (5) Poppet 2
- (6) Plate

(a) A Chamber

C : C (Cylinder) Port

P : P (Pump) Port

T1 : T1 Port

(To Transmission Case)

12670M80020

# Full Version Available

Kubota L2600 Tractor Workshop Manual

This is a short preview. The complete manual contains all chapters, wiring diagrams, torque specifications and full service procedures.

**VIEW THE FULL MANUAL**

<https://machinecatalogic.com/kubota-l2600-tractor-workshop-manual/>