


WSM

WORKSHOP MANUAL
FRONT LOADER

LA1403AU

Kubota

Self-leveling on Boom Up (Figure 3)



3TVAAAELP007A

- (18) Check Valve
- (21) Passage H
- (23) Raising Sequence Spool


- A2 : A2 Port (Connected Bucket Cylinder Rod Side)
- B2 : B2 Port (Connected Bucket Cylinder Bottom Side)

- c-c : Bucket Section
- d-d : Sequence Section
- e-e : Self-leveling Section

- (a) Low Pressure
- (b) Middle Pressure
- 1 to 22 : Oil Flow

9Y1210547FLM0018US0

Boom Floating (Figure 3)



A2 : A2 Port (Connected Bucket Cylinder Rod Side)

B2 : B2 Port (Connected Bucket Cylinder Bottom Side)

c-c : Bucket Section

d-d : Sequence Section

e-e : Self-leveling Section




(a) Low Pressure

(b) Middle Pressure

1 to 14 : Oil Flow

9Y1210547FLM0033US0

(2) Overload Relief Valve



Overload relief valve in this control valve is a combination valve combining a relief operation and anti-cavitation operation.

■ Relief Operation

When the control valve is in the neutral position, both cylinder ports of control valve are blocked by the spool. If an external load is imposed on the cylinder, pressure builds in the circuit.

When the pressure exceeds the set level of the overload relief valve, the relief valve opens and the oil returns to tank. In this way, the hydraulic circuit and actuator are protected from excessive pressure.

■ Anti-cavitation Operation

Overload relief valve also has anti-void function. If negative pressure takes place in the circuit, the oil is fed from the tank to eliminate the negative pressure.

- | | |
|---------------------------|---------------------|
| (1) Overload Relief Valve | (7) Piston Poppet |
| (2) Control Valve | (8) Lock Nut |
| (3) Housing | (9) Adjusting Screw |
| (4) Check Valve Poppet | (10) Pilot Spring |
| (5) Relief Valve Poppet | (11) Pilot Poppet |
| (6) Piston Spring | (12) Pilot Section |

9Y1210547FLM0045US0

Relief Operation

[When the actuator port pressure is lower than the setting]



The cylinder port **HP** is applied to the seat **B** in the following route : first through the throttle **a** of the piston poppet (1) built in the relief valve poppet (5), second through the spring chamber **A**, and then through the circular clearance between the adjusting screw (4) and the piston poppet (1). This cylinder port **HP** works to open the pilot poppet (2). Because the piston spring (3) has not reached the set pressure, however, the valve stays shut. In this way, the seat remains intact and the relief valve poppet (5) stays shut.

- | | |
|-------------------------|---------------------------|
| (1) Piston Poppet | HP : High Pressure |
| (2) Pilot Poppet | LP : Low Pressure |
| (3) Piston Spring | A : Chamber |
| (4) Adjusting Screw | B : Seat |
| (5) Relief Valve Poppet | a : Throttle |

9Y1210547FLM0046US0

[2] HYDRAULIC HOSE

(1) Standard Type



Hydraulic Hoses

1. Slowly release all hydraulic pressure by moving the hydraulic control lever in all directions.
2. Disconnect the four hoses with quick couplers at the control valve and place them on the right side of the boom.
3. Place the protective caps and plugs on the quick coupler ends.
4. Start the engine and slowly back the tractor away from the loader.

(1) Protective Plug

9Y1210546FLS0006US0

Full Version Available

Kubota LA1403AU Front Loader Workshop Manual

This is a short preview. The complete manual contains all chapters, wiring diagrams, torque specifications and full service procedures.

[VIEW THE FULL MANUAL](#)

<https://machinecatalogic.com/kubota-la1403au-front-loader-workshop-manual/>