




Service Manual

Chassis & Mast

GC35K	AT87B-00001-up
GC40K	AT87B-00001-up
GC40K STR	AT87B-00001-up
GC45K SWB	AT87B-00001-up
GC45K STR	AT87B-00001-up
GC55K	AT88B-00001-up
GC55K STR	AT88B-00001-up
GC60K	AT89B-00001-up
GC70K	AT89B-00001-up
GC70K STR	AT89B-00001-up

4.2 Removal Sequence (1)



505724

- | | |
|------------------------------------|---|
| 1. Light harnesses, Overhead guard | 6. Reserve tank |
| 2. Engine cover, Seat | 7. Steering wheel, Forward/reverse lever assembly |
| 3. Radiator cover | 8. Transmission oil hoses |
| 4. Floor plate | 9. Transmission oil cooler, Bracket |
| 5. Battery cable, Battery | 10. Cowl |

10. Inspection and Repair After Disassembling Wheel Brake


10.1 Backing Plate

- (1) Check the backing plate for cracks.
- (2) Check the tightening torque of mounting bolts.

Item	Tightening torque
Check the mounting bolts	238.3 to 284.3 N·m (24.3 to 29.3 kgf·m) [53.5 to 63.9 lbf·ft]

10.2 Shoe and Lining Assembly

- (1) Check the lining and shoe for cracks or breakage.
- (2) Replace the lining if severely stained with oil, burned, or deteriorated.
- (3) Check the lining thickness. If the thickness exceeds the service limit, replace the lining.



609132

Item	Standard value	Repair limit
Lining thickness	10 mm (0.39 in.)	4.2 mm (0.16 in.)


10.3 Brake Drums

If uneven wear or damage is found inside each brake drum, grind, and repair.

Item	Standard value	Repair limit or Service limit
Brake drum internal diameter	$317.5^{+0.2}_0$ mm ($12.500^{+0.008}_0$ in.)	318.5 mm (12.539 in.)

10.4 Adjusting Screw

Check for wear on wheel teeth. Also check if the wheel rotates smoothly.




609133

Without spring washer										
Nominal size mm (in.)	Pitch mm (in.)	 500247			 500248			 500249		
		N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft	N·m	kgf·m	lbf·ft
10 (0.39)	1.5 (0.06)	39.2	4.0	28.9	51.0	5.2	37.6	79.4	8.1	58.6
12 (0.47)	1.75 (0.07)	69.6	7.1	51.4	90.2	9.2	66.5	135.3	13.8	99.8
14 (0.55)	2 (0.08)	112.8	11.5	83.2	146.1	14.9	107.8	215.7	22.0	159.1
16 (0.63)	2 (0.08)	172.6	17.6	127.3	224.6	22.9	165.6	323.6	33.0	238.7
18 (0.71)	2.5 (0.10)	239.3	24.4	176.5	311.9	31.8	230.0	451.1	46.0	332.7
20 (0.79)	2.5 (0.10)	336.4	34.3	248.1	437.4	44.6	322.6	630.6	64.3	465.1
22 (0.87)	2.5 (0.10)	392.3	40.0	289.3	587.4	59.9	433.3	842.4	85.9	621.3
24 (0.95)	3 (0.12)	578.6	59.0	426.7	753.2	76.8	555.5	1088.5	111.0	802.9
27 (1.06)	3 (0.12)	852.2	86.9	628.5	1108.2	113.0	817.3	1588.7	162.0	1771.7
30 (1.18)	3.5 (0.14)	1140.5	116.3	841.2	1481.8	151.1	1092.9	2168.3	221.1	1599.2
33 (1.30)	3.5 (0.14)	1563.2	159.4	1153.0	2031.9	207.2	1498.7	2915.5	297.3	2150.4
36 (1.42)	4 (0.16)	1972.1	201.1	1454.6	2564.4	261.5	1891.4	3765.8	384.0	2777.5
39 (1.54)	4 (0.16)	2610.5	266.2	1925.4	3393.1	3469.0	2502.6	4845.5	494.1	3573.8
42 (16.5)	4.5 (0.18)	3241.1	330.5	2390.5	4212.9	429.6	3107.3	6044.8	616.4	4458.4

10. Assembling Axle Shaft and Hub

10.1 Assembly Sequence



609188

- | | |
|--|------------------------------------|
| 1. Retainer, O-ring | 3. Taper roller bearing (inner) |
| 2. Front hub drum assembly
Taper roller bearing (outer), Oil seal,
Taper roller bearing, Spacer and Oil seal | 4. Locknut, Lock washer, Bolt |
| | 5. Axle shaft, Bolt, Spring washer |
| | 6. Front tire, Wheel nut |

Full Version Available

**Caterpillar GC40K STR Forklift Engine Service and Schematic Manual
(99739-82110)**

Caterpillar GC40K STR service manual, engine repair, testing, schematics, and service data in PDF. Instant PDF download.

[VIEW THE FULL MANUAL](#)