

SERVICE MANUAL

**NR14N2S, NR14N2HS
NR16N2, NR16N2H, NR16N2S
NR16N2HS, NR16N2C, NR16N2HC
NR20N2H, NR20N2X
NR25N2X**




Table 5. Schematic diagram identifiers

IDENTIFIER	DESCRIPTION
S#	Switches and other state changing devices (for example, most sensors).
#F#	Fuse
J#	Reference. All references marked with an even "J" (for example J2) are positive (+). All references marked with an odd "J" (for example J3) are negative (-).
M#	Motor
V#	Diode
A#	Controllers and displays
K#	Contactors and relays
X#	Connector. Contact numbers are marked on individual wires.
XX#	Splice. Multiple wires are connected together at this point.

Figure 111 shows the reference to which Figure 110 referred.



Figure 111. Page 8, zone 16, wiring reference J14





Figure 161. Location of the service socket


11.1.1 Connect TruckTool to the service socket

The service socket is behind the fuse cover. You must open the cover before you can connect TruckTool to it.

1. Open the fuse cover.




2. Connect TruckTool to the service socket.



The plate protects the operator from impacts in narrow and tight areas.

15.16.1 Install the left shoulder protection plate

1. Install the left shoulder protection plate to the left side of the operator compartment with screws.



15.17 Fire extinguisher




Figure 185. Fire extinguisher overview

In case of a fire in the truck, the fire extinguisher can be used as a preliminary means of putting out the fire.



NOTE: With this option, the height of the overhead guard increases by 100 mm.

8.3.9.1 CNA external connector

CONNECTION	DESCRIPTION
A3 CHA (XA3A/3) (encoder channel A)	A channel of the steering motor encoder.
A4 CHB (XA3A/4) (encoder channel B)	B channel of the steering motor encoder.
A5 GND (XA3A/5) (encoder GND)	Ground for the steering motor encoder.
A6 PTHM (XA3A/6) (temperature sensor input)	Input for the motor temperature sensor.
A7 GND (XA3A/7) (temperature sensor GND)	Ground for the motor temperature sensor.
A8 GND (XA3A/8) (QL channel GND)	Ground for the steering wheel QL channel.
A9 PCOIL (XA3A/9) (brake supply)	Brake supply (single safety contact).
A11 SW1 (XA3A/11) (reference sensor 90 degrees)	Steering reference sensor 90 degree switch.
A12 SW2 (XA3A/12) (reference sensor 0 degrees)	Steering reference sensor 0 degree switch.
A15 KEY-IN (XA3A/15) (key)	Key line supply for EPS.
A16 VCC2 (XA3A/16) (encoder supply)	Supply for the motor encoder.
A17 QL (XA3A/17) (QL channel)	Steering wheel QL channel.
A19 GND (XA3A/19) (GND)	Ground for the steering wheel DL channel.
A20 DL (XA3A/20) (DL channel)	Steering wheel DL channel.
A22 CANH (XA3A/22) (CANH)	High signal of CAN bus.
A23 CANL (XA3A/23) (CANL)	Low signal of CAN bus.

CODE	TRUCKTOOL DESCRIPTION	DISPLAY DESCRIPTION	MESSAGE TYPE
8A235	CNA4 open	Internal alarm Call Service	Alarm
	The XA1A/4 input is open, and the emergency input parameter is set to Present (it must always be Absent). This alarm occurs when there are incorrect parameters in the controller. NOTE: During resistance measurements, make sure that the battery connector is disconnected, and that the voltage at the measured circuit is 0 V. • Read the alarm status from each controller. Try to make an overall picture of the root cause for the event code(s). • Make sure that the battery is not damaged. Measure the battery voltage when idle, and during full speed lift. The battery voltage must stay over 38 V. • Make sure that the fuses are not damaged. • Make sure that the truck frame is isolated from the battery positive and negative. Measure this from both sides of the drive contactor. Make sure that there is no short-circuit or low resistance between the positive and negative from the terminals of any controller (B+ and B- terminals). • Make sure that the wiring harness is not damaged. Make sure that the related connections do not have loose pins etc. • Set the truck back to the default settings. Run the truck model configuration wizard. • If the default settings are not a solution to the problem, flash the controller and run the wizards again. • If the flashing does not help, replace the current controller with another controller. NOTE: If the controller replacement does not help, install the original controller back to the truck. • If the controller replacement does not help, evaluate the possible root causes for the alarm again. Also, see if there are other alarm messages active in the system. • Clear the online error codes in TruckTool. Set the power of the truck OFF and ON again: other error codes can show up during start-up.		




Figure 16. Battery discharge level almost empty

Center information area




Figure 17. Center information area overview

1. Speed indicator
2. Height indicator
3. Driving direction indicator

In a normal operating situation, the center information area displays the speed and height indicators. In addition, the driving direction of the truck is indicated with two arrows on the opposite sides of the center information area. If no driving direction is set, the arrows are blinking. When the driving direction is set, the selected direction is indicated with a solid blue colored arrow and the other arrow turns gray.

Parking brake indicator

The parking brake indicator is displayed in the bottom left-hand corner of the truck display. The parking brake must be engaged before the operator leaves the truck.

Steering controller connectors.....	229
Traction controller	222
Traction controller connectors ...	218, 223
Vehicle controller.....	218

L

Lifting points

Hoist points	58
Jack points	57

Load backrest	157
---------------------	-----

Load wheels

Remove the load wheels	83
------------------------------	----

Lubrication	696
-------------------	-----

M

Magnetic brake

See	<i>Motor compartment</i>
-----------	--------------------------

Main rollers

Replace the main rollers.....	136
-------------------------------	-----

Maintenance check list.....	692
-----------------------------	-----

Mast

Disassemble the mast	112
Fork inspection.....	118
Lubricant recommendations	105
Mast maintenance	104

Mast chains

Adjust the mast chains	130
Examine the tension of the mast chains	129
Inspect the mast chains.....	123
Replace the mast chains	130

Motor compartment

Adjust the air gap of the magnetic brake	245
Coil resistance measurement	244
Install the magnetic brake	244
Magnetic brake.....	243
Motor compartment	53, 234

O

Operating devices.....	26
------------------------	----

Arm rest	28
----------------	----

Pedals	47
--------------	----

Order spare parts.....	66
------------------------	----

P

Pedals

Accelerator pedal	212
-------------------------	-----

Brake pedal	214
-------------------	-----

Operator presence pedal.....	210
------------------------------	-----

Pump controller

See	<i>Instrument panel</i>
-----------	-------------------------

Pump motor	247
------------------	-----

Lubricate the pump axle splines	249
---------------------------------------	-----

Remove the pump motor	249
-----------------------------	-----

Replace the HALL sensor	251
-------------------------------	-----

R

Reach carriage

Adjust the guidance rollers of the reach carriage	91
--	----

Lubricate the rollers of the reach carriage	90
--	----

Remove the reach carriage	94
---------------------------------	----

Remove the reach cylinder.....	95
--------------------------------	----

Sensors of the reach carriage	93
-------------------------------------	----

S

Sensors

Battery lock sensor	256
---------------------------	-----

Height reference sensor	258
-------------------------------	-----

Pressure sensor	257
-----------------------	-----

Reach end stop, retract limit, retract end stop and reach limit switch	255
---	-----

Sensor locations.....	53
-----------------------	----

Sensors.....	252
--------------	-----

Steering reference sensor	254
---------------------------------	-----

Steering wheel sensor.....	252
----------------------------	-----

Side cylinders

Bleed out air from the side cylinders..	149
---	-----

Full Version Available

Caterpillar NR16N2H Reach Truck Service and Operator Manual (622076-EN-C)

Caterpillar NR16N2H Reach Truck service manual, covers mast, hydraulics, drive system, wiring, and diagnostics. Instant PDF download.

[VIEW THE FULL MANUAL](#)