



# Service Manual

## Chassis & Mast

### **FBC15K, FBC18K, FBC18KL**

A3BC1-10200-up

A3BC1-20200-up

A3BC1-30200-up

A3BC2-40200-up

### **FBC20K, FBC25K**

A3BC2-10200-up

A3BC2-20200-up

A3BC2-30200-up

A3BC2-40200-up

A3BC2-80200-up

### **FBC25KE, FBC25KL, FBC30K**

A3BC3-10200-up

A3BC3-20200-up

A3BC3-30200-up

A3BC3-40200-up

A3BC3-80200-up

### **FBC30KL**

A3BC4-40200-up

## Suggestions for Disassembly

1. Remove the bevel pinion shaft 6 as follows:

- (1) Using a chisel, cut the staked portion of the nut 4, taking care not to damage the bevel pinion shaft.
- (2) Hold the input gear 15 with the special tool to prevent the bevel pinion 6 from rotating, then remove the nut 4 and shims 5.

Special tool needed

|                       |               |
|-----------------------|---------------|
| Transfer bearing tool | 97E67 - 00100 |
|-----------------------|---------------|

- (3) Using the bevel pinion puller (special tool), pull the bevel pinion 6 out of the bearing cone 9 (See the drawing on the right).




Special tool needed

|                     |               |
|---------------------|---------------|
| Bevel pinion puller | 91268 - 00300 |
|---------------------|---------------|

- (4) If the bearing cone 8 needs to be removed, use a bearing puller and a press to pull it from the bevel pinion 6.
- (5) If the bearing cups 12 and 13 need to be removed, use a bearing cup puller to pull them out of the transfer case 18.

### NOTE


- (1) The taper roller bearing cup and cone are an exclusive pair. If either the cup or cone of a pair is faulty, replace them as a set.
- (2) The removed shims should be kept together until they are reinstalled. (This only applies when the bevel pinion and/or taper roller bearing are/is reused.)
- (3) The bevel pinion and bevel gear are an exclusive pair. If either of them is defective, replace them as a set.



## STEERING GEAR: REASSEMBLY

### Suggestions:

**NOTE:** These instructions are more in depth than routine service should require. **DO NOT** disassemble the steer gear further than required to replace serviceable components. Doing so may result in replacing entire gear.



- 1 Install o-ring (82,6 [3.25 OD) on tank plug.
- 2 Assemble tank plug into housing. Torque tank plug to 47,5 Nm [35 lb-ft].
- 3 Install o-ring (82,6 [3.25 OD) into groove.
- 4 Lay gerotor on the housing, lining up bolt holes, check alignment per scribed (mark) line..
- 5 Install pressure seal into inside cavity of mounting cap (25,4 [1.00] OD x 3,2 [.12] W).
- 6 Install dust seal (25,4 [1.00] OD x 3,2 [.12] W) into mounting cap.
- 7 Install manual steering balls (9) into spool. Grease balls to retain in holes.
- 8 Insert spool into sleeve, lining up the spring slots.
- 9 Insert smaller centering spring onto spool/ sleeve assembly.
- 10 Install larger centering spring onto spool/ sleeve assembly.
- 11 Insert shorter drive pin.
- 12 Install drive tube assembly, wider groove downward.
- 13 Slide spool/sleeve/tube assembly into housing bore, through the gerotor star. Before spool/sleeve/tube reaches the tank plug, line up pin slot in gerotor with pin slot in drive tube, insert longer drive pin, then continue to slide spool/sleeve/tube into housing until the pin sets into the gerotor.
- 14 Install the retaining ring into groove on spool.
- 15 Install bearing race-bearing-bearing race onto the retaining ring.
- 16 Grease o-ring (82,6 [3.25] OD) and install into mounting cap.
- 17 Carefully install mounting cap over spool so as not to cut or damage seals. Lining up bolt holes, check alignment per scribed (mark) line.
- 18 Install 5 bolts. torque to 23Nm [200 in-lb].

|               | Complaint                 | Possible Cause                                                                                                                                               | Remedy                                                                                                                                                                                                 |
|---------------|---------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Parking Brake | Lever stroke is too small | Lining-to-drum clearance too small                                                                                                                           | Readjust                                                                                                                                                                                               |
|               | Squeals during traveling  | Lining-to-drum clearance too small                                                                                                                           | Readjust                                                                                                                                                                                               |
|               |                           | Brake drum badly distorted                                                                                                                                   | Repair or replace                                                                                                                                                                                      |
|               | Will not apply            | Parking brake cable longer than specified<br><br>Linings worn to service limit<br>Lining-to-drum clearance too small<br>Lack of brake lever operating effort | Check drum-to-lining clearance and, if brake will not apply, turn adjusting knob clockwise<br><br>Replace shoe & lining assembly<br>Readjust<br>Readjust to 25 to 30 kgf (55 to 66 lbf) [245 to 294 N] |

|                 | Complaint                               | Possible Cause                                                                                                 | Remedy                            |
|-----------------|-----------------------------------------|----------------------------------------------------------------------------------------------------------------|-----------------------------------|
| Steering System | Hard steering                           | a) Overloaded steer axle<br>b) Damaged mechanical linkage                                                      | Reduce load<br>Replace            |
|                 |                                         | c) Dry mechanical linkage joints<br>d) Mechanical joints too tight<br>e) Kingpin bearings improperly preloaded | Lubricate<br>Readjust<br>Readjust |
|                 | Truck wanders                           | a) Damaged or worn mechanical linkage<br>b) Loose cylinder piston                                              | Replace<br>Replace cylinder rod   |
|                 | Truck drifts                            | a) Damaged or worn mechanical linkage<br>b) Tire diameter differs between right and left                       | Replace<br>Replace tire           |
|                 | Erratic steering                        | Loose cylinder piston                                                                                          | Replace cylinder rod              |
|                 | Excessive free play at steered wheels   | Damaged or worn linkage between cylinder and steered wheels                                                    | Replace                           |
|                 | Axle shimmy                             | a) Excessive clearance between the kingpin and its bearings<br>b) Worn or damaged hub bearing                  | Repair or replace<br>Replace      |
|                 | Rear tires wear prematurely or unevenly | Tire on one side differs in kind or brand from that on the other side.                                         | Replace tires                     |
|                 |                                         |                                                                                                                |                                   |
|                 |                                         |                                                                                                                |                                   |

## SERVICE BRAKES: DISASSEMBLY


---

### Suggestions

#### Removing Return Springs

Use a special tool to remove the return springs.


| Special Tool   | Part Number |
|----------------|-------------|
| Spring remover | 64309-15411 |



#### Removing Hold-Down Springs

Use a special tool to remove the hold-down springs.

| Special Tool   | Part Number |
|----------------|-------------|
| Spring remover | 64309-15412 |



## Full Version Available

### Mitsubishi FBC30K Forklift Service Manual (99759-73110)

Mitsubishi FBC30K forklift service manual PDF, covers drive, hydraulics, mast, wiring, and controller diagnostics. Instant PDF download.

**[VIEW THE FULL MANUAL](https://machinecatalogic.com/mitsubishi-fbc30k-forklift-service-manual-99759-73110/)**

<https://machinecatalogic.com/mitsubishi-fbc30k-forklift-service-manual-99759-73110/>