



Service Manual

Chassis & Mast

FD70NH	30E-00001-09999
FD80NH	30F-00001-09999
FD100NH	30G-00001-09999




Fig. 3.2 Drive Axle (8 ton, 10 ton)

5.2 MAINTENANCE

5.2.1 DISASSEMBLING STEERING GEAR BOX

- (1) Hold the steering gear box in a vise.




Fig. 5.10

- (2) Remove the box nut and packing from the adjustment screw. Remove the side cover mounting bolts and turn the adjustment screw clockwise. This causes the side cover to come off.

Note: Exercise care not to lose the "O"-ring fitted to the side cover.

Remove the adjustment screw and shims fitted to the sector shaft.




Fig. 5.11

- (3) Rotate the worm shaft so that the sector shaft teeth are positioned as shown in Figure 5.12. Lightly tapping the sector shaft serration by hand, remove the sector shaft.




Fig. 5.12

- (4) Remove the bolts securing the end cover and detach the end cover, using caution not to lose the "O"-ring.




Fig. 5.13

8.2 PREVENTIVE MAINTENANCE

8.2.1 DISASSEMBLY AND MAINTENANCE OF ORBITROL

Prior to attempting to disassemble the orbitrol, clean the exterior of the unit and select a clean working place.

- (1) Lightly hold the flange of the orbitrol in a vise equipped with a soft jaws (copper or other inserts) with the end cap upward. Do not hold it strongly.




Fig. 8.9

- (2) Remove the fitting bolts from the end cap and remove the end cap.

Note: One of the seven bolts has a different shape from the others. Mark the housing to insure correct reassembly.

Remove the "O"-ring from the end cap.




Fig. 8.10

- (3) Remove the spacer from the spline section of the rotor set and remove the rotor set.

Note: Use caution not to lose the rotor set star.

Remove the "O"-ring from the rotor set.




Fig. 8.11




Fig. 4.12 Wheel Brake (8 ton, 10 ton trucks)

Full Version Available

Mitsubishi FD100NH Forklift Engine Service Manual (99709-21100)

Mitsubishi FD100NH forklift engine service manual, PDF repair guide for engine diagnostics, teardown, and adjustment. Instant PDF download.

VIEW THE FULL MANUAL

<https://machinecatalogic.com/mitsubishi-fd100nh-forklift-engine-service-manual-99709-21100/>