

Operator's Manual

ZAXIS

27U-2

30U-2

35U-2

40U-2

50U-2

IGNITION BLOCK SYSTEM


(English, German, French, Italian and Dutch Operator's Manuals are combined.)

OPERATION PROCEDURE


Unlocking

1. Turn the key switch (1) ON. Then, all the numeric keys are lit.
2. Input the 1st digit of the four-digit password.
3. Similarly, input the 2nd digit.
4. Similarly, input the 3rd digit.
5. Similarly, input the 4th digit.
6. If the inputted numerals coincide with those of the password, the buzzer sounds twice, and unlocking is done. In this condition, when the key switch (1) is turned ON, the engine can be started.


 **NOTE:** In case mistaken inputting of the password has been found out, the input can be cancelled by pushing Key C (3). Alternatively, redo from the beginning by turning the key switch (1) OFF.



M1M7-01-007



M1M7-OP1-01-002



M1M7-OP1-01-003

MÉMO

machinecatalogic.com

MEMO

machinecatalogic.com

Vollversion verfügbar

Hitachi ZX50U-2 Hydraulikbagger Zündanlage Betriebsanleitung (EM1M7-OP1-2)

Hitachi ZX50U-2 Betriebsanleitung als PDF für Bedienung, Wartung, Sicherheit und Fehlersuche. Sofort als PDF herunterladen.

VOLLSTÄNDIGES HANDBUCH ANSEHEN

Buch-Nr.: EM1M7-OP1-2 · Seitenzahl: 72 · Dateianzahl: 1 · Sprache: Deutsch