

PRINTED IN USA

COPYRIGHT© 2000
BRODERSON MFG. CORP.
LENEXA, KANSAS 66215

PARTS MANUAL

IC-200-1C & 2C

P/N 990-30075

REVISED 1/11/00

OWNER:

SOLD AND SERVICED BY:


MODEL NO. _____

SERIAL NO. _____

ENGINE & TRANSMISSION INSTALLATION (GM V6 4.3L GAS) 4X4


ITEM	QTY	PART NO.	DESCRIPTION
82	2	0-222-16001	LOCKWASHER 5/8" DIA.
83	8	0-222-04001	FLATWASHER 1/2" DIA.
84	4	1-600-21036	FLATWASHER SPECIAL
85	2	0-222-06001	FLATWASHER 5/8" DIA.
86	3	0-222-10001	LOCKWASHER 1/4" DIA.
87	26	0-222-11001	LOCKWASHER 5/16" DIA.
88	1	0-221-00001	NUT, HEX 1/4 - 20NC
89	8	0-222-14001	LOCKWASHER 1/2" DIA.
90	1	0-600-94400	EXHAUST PIPE - MUFFLER END
91	18	0-221-01001	NUT, HEX 5/16 - 18NC
92	6	0-221-02001	NUT, HEX 3/8 - 16NC
93	8	0-221-04001	NUT, HEX 1/2 - 13NC
94	2	0-221-96001	NUT, LOCK 5/8 - 11NC
95	3	0-222-10002	LOCKWASHER #10 DIA.
96	1	A-600-94414	EXHAUST PIPE - W/GASKET R.H.
97	2	0-600-94433	EXHAUST FLANGE MOD.
98	1	0-220-13006	BOLT, HEX HD. 7/16 - 20NF X 3 1/2" LG. GR.8
99	3	0-222-12002	LOCKWASHER 3/8" DIA. HI-COLLAR
100	1	0-570-40001	BUSHING 1/4" TO 1/8"
101	1	0-570-30002	ELBOW 45 DEG. 1/8" STREET
102	1	0-570-50026	TEE STREET 1/8" NPT
103	1	0-400-04950	SENDER HOUR METER TWO TERM.
104	1	0-600-40213	OIL PRESSURE SENDER
105	1	0-400-04302	SENDER HOUR METER ONE TERM.
106	1	0-570-10001	COUPLING 1/8"
107	1	0-222-00003	FLATWASHER 1/4" DIA.
108	1	C-042-00020	ADAPTER - CARBURETOR
109	2	0-223-00302	SCREW, MACH. FL. HD. 5/16 - 18NC X 1" LG.
110	1	C-400-01441	GM V6 ENGINE HARNESS
111	REF	0-042-00001	ELECTRIC FUEL PUMP
112	1	0-400-18010	RELAY 12V
113	2	0-223-01406	SCREW, RD. HD. #10 - 32NF X 1 1/4" LG.
114	1	0-222-00005	FLATWASHER #10 DIA.
115	2	0-514-03001	ELBOW WEATHERHEAD #69 X 5A
116	3	0-220-00003	BOLT, HEX HD. 1/4 - 20NC X 3/4" LG.
117	1	B-209-00352	RADIATOR BAFFLE - GM V6
118	5	0-222-00008	WASHER, FENDER #8 X 7/8 OD
119	4	0-220-01004	BOLT, HEX HD. 5/16 - 18NC X 3/4" LG.
120	3	0-220-32010	BOLT, SOC. HD. 3/8 - 16NC X 2" LG.
121	3	0-222-11002	LOCKWASHER 5/16" DIA. HI-COLLAR

ROOM STRUCTURAL PROTECTION (BSP-2)



ITEM	QTY	PART NO.	DESCRIPTION
0	REF	C-600-90155	BOOM STRUCTURAL PROTECTION SYSTEM
1	1	0-400-04986	PRESSURE SW.
2	1	0-514-04006	ELBOW #6 - 2CTX-S
3	1	0-516-85003	TEE #6R6X-S
4	1	0-519-40001	CAP #6FNTX-S
5	1	1-510-40237	TUBE ASSY. 3/8" DIA. X 6" LG.
6	1	1-514-55012	ELBOW MOD.
7	1	1-570-20047	PIPE PLUG MOD.
8	1	0-400-22012	STRAIN RELIEF
9	1	B-783-02587	SUPPORT BAR - PRESSURE SW.
10	3	0-400-22003	CONNECTOR
11	2	0-400-02236	TERMINAL EYE
12	1	B-651-00086	PLACARD, WARNING STRUCTURAL PROTECTION SYS.
13	2	0-223-00908	SCREW, HEX HD. #10 - 32NF X 2" LG.
14	2	0-222-10002	LOCKWASHER #10 DIA.
15	A/R	0-400-06106	WIRE - 16GA. - 2 COND.
16	REF	C-600-90156	BSP - 2 - K FIELD KIT

WINDSHIELD WASHER INSTALLATION (WA-1)



ITEM	QTY	PART NO.	DESCRIPTION
0	REF	3-600-00698	WINDSHIELD WASHER INSTALLATION
1	1	0-600-93057	WINDSHIELD WASHER KIT
2	2	0-223-15203	HEX HD. SCREW 1/4-20NC X 3/4 LG.
3	2	0-222-00003	FLATWASHER 1/4 DIA.
4	1	0-222-10002	LOCKWASHER #10
5	1	0-221-10002	NUT, HEX #10-32NF
6	1	1-650-00256	PLACARD, WINDSHIELD WASHER
7	1	0-223-01101	SCREW, RND. HD. #10-32NF X 3/4 LG.
8	10'	0-503-11005	HOSE, 3/16 DIA.
9	5'	0-400-01307	WIRE 16 GA. RED
10	2	0-400-02213	TERMINAL #10 RING
11	2	0-400-02202	CRIMP CONNECTOR

Full Version Available

Broderson IC-200-1C Pick and Carry Crane Parts Manual

Broderson IC-200-1C pick and carry crane parts manual, parts lists, exploded views and assemblies in PDF. Instant PDF download.

VIEW THE FULL MANUAL

<https://machinecatalogic.com/broderson-ic-200-1c-pick-and-carry-crane-parts-manual/>

Book No: 990-30075 · File Pages: 170 · File Count: 1 · File Language: English