




**DS350 GRAPHIC
(BOOM CONTROL SYSTEM)**

**DS350 GRAPHIC
MODULAR**

**DS350 GRAPHIC
MODULAR**

iFLEX5 SYSTEM

P.A.T. - L.M.I. SYSTEM MANUAL


GROVE®

P.A.T. DS350 Graphic


E12 ERROR CODE

The following step - by - step procedures, with illustrations, are designed to assist in eliminating error code E12. Since various problems can cause an E12, these procedures will check out the complete piston pressure transducer system.


BOOM LENGTH PERCENTAGE PROBLEM



DS350 Graphic Modular
GRAPHIC CONSOLE (Vertical 1319) - PARTS LIST



#	PART #	QTY	DESCRIPTION	#	PART #	QTY	DESCRIPTION
1	9-333-103431	1	PANEL FRONT	17	9-333-102612	1	DUST CAP
2	9-333-103552	1	HOUSING	18	9-333-103222	1	BOARD, TERMINAL
3	9-333-103302	1	BOARD, PUSHBUTTON SET				INTERFACE FOR
4	9-333-103406	1	SWITCH, KEY				LIGHTBAR
5	9-333-101691	1	KEY SPARE				
6	9-333-102359	6	SCREWS, FRONT PANEL				
7	9-333-103299	1	BOARD				
8	9-333-103223	1	SEALING, FRONT PANEL				
9	9-333-103300	1	TERMINAL BOARD				
10	9-333-101727	1	LOCKNUT				
11	9-333-103169	1	TOOTHWASHER, M12				
12	9-333-101547	1	LOCKNUT				
13	9-333-103043	1	CANNON CONN., 7 SOCKET				
14	9-333-102047	1	HOLE PLUG				
15	9-333-102746	1	STRAIN RELIEF				
16	9-333-102482	1	GASKET				



Full Version Available

PAT iFLEX5 Load Moment Indicator Service Manual (031-300-190-154)

PAT iFLEX5 load moment indicator service manual with wiring diagrams, error codes and troubleshooting for DS350 systems. Instant PDF download.

[VIEW THE FULL MANUAL](#)

File Pages: 664 · File Count: 3 · File Language: English