



TADANO

Publication No. GR-500XL-1/P3(U)-1EJ

Parts Catalog

01

Rough Terrain Crane

Model **GR-500XL-1**



Applicable Serial No.

540640~

TADANO LTD.

組立名称 ラジエータ
Assembly Name RADIATOR

PQ102-0112-01



組立名称 ラジエータ
Assembly Name RADIATOR

FIG. PQ102-0112-01


仕様番号 A < GR-500-1-00314 >
Specification No.

指示番号 Key No.	部品番号 Part No.	部品名称 Part Name	Q'ty Per Section 個数													実施号機 (変更番号)	Serial No. Modifi. No.	ページ Page
			A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	
2	363-613-23020	HOSE	1															
3	363-613-23030	HOSE	1															
4	363-613-23040	HOSE	1															
5	363-613-23050	HOSE	1															
6	363-608-03050	CLIP	2															
7	363-608-03060	CLIP	4															
8	363-608-03070	CLIP	1															
9	363-608-03080	CLIP	1															
10	363-608-03090	GUIDE (FAN SHROUD)	1															
11	363-605-91050	CLAMP	1															
12	363-605-91030	GUIDE	1															
13	363-609-53040	SUPPORT	2															
14	363-613-23060	SUPPORT	1															
15	363-613-23070	HOSE	1															
16	363-613-23080	CLIP	2															
17	363-613-23090	BOLT (WITH WASHER)	2															
50	363-613-25060	RADIATOR ASSY (WITH INTERCOOLER)	1															
60	363-613-25070	RADIATOR ASSY	1															
70	363-613-25080	COOLER ASSY	1															
141	363-609-57510	CAP	1															

組立名称 トランスミッション
Assembly Name TRANSMISSION

PR140-0043-00

300



組立名称 トランスミッション
Assembly Name TRANSMISSION

FIG. PR140-0043-00

スペック番号 A < GR-500-1-00314 >
Specification No.

指示番号 Key No.	部品番号 Part No.	部品名称 Part Name	Q'ty Per Section 個数													実施号機 (変更番号)	Serial No. Modifi. No.)	ページ Page
			A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	
1	363-505-55010	CLUTCH PACK, TRANSMISSION (F2, R)	1															547
2	363-505-55020	CLUTCH PACK, TRANSMISSION (F1, F3)	1															549
3	363-505-55030	CLUTCH PACK, TRANSMISSION (H1-LOW)	1															551
4	363-505-55040	HOUSING (MISSION)	1															
5	363-505-55050	GASKET	1															
6	363-505-55060	HOUSING (COVER)	1															
7	363-505-55070	GASKET	1															
8	363-505-55080	HOUSING (FRONT)	1															553
9	363-505-55090	VALVE, CONTROL	1															
10	363-505-55100	SOLENOID ASSY	1															555
11	363-702-07290	FLANGE	1															
12	363-505-55110	SHAFT ASSY	1															
13	363-505-55120	GEAR (K)	1															
14	363-505-55130	GEAR (U)	1															
15	363-505-35150	SHAFT	1															
16	363-504-55140	FLANGE	2															
17	363-502-75130	SLEEVE (B)	1															
18	363-504-55150	SEAL, OIL	1															
19	363-504-56050	SEAL, OIL	1															
20	910-671-03500	O-RING <4E P35>	1															
21	363-703-55130	WASHER	1															
22	901-035-16040	BOLT <M16X40>	3															
23	363-502-65160	PIN <10X28>	4															
24	363-505-55140	GEAR (W)	1															
25	363-505-55150	SHAFT	1															
26	363-505-55160	CASE (SPEEDOMETER)	1															
27	363-505-55170	GASKET	1															
28	363-505-55180	COVER	1															
29	363-505-55190	GASKET	2															
30	363-505-55200	COVER	1															
31	363-505-55210	GASKET	1															
32	363-505-55220	COVER	1															
33	363-505-35170	SEAL, OIL	2															
34	363-502-75650	SEAL, OIL	2															
35	363-505-35180	COVER (C)	1															

Full Version Available

Tadano GR-500XL-1 Rough Terrain Crane Parts Manual

Tadano GR-500XL-1 rough terrain crane parts manual, PDF with parts lists, exploded views and assembly breakdowns. Instant PDF download.

VIEW THE FULL MANUAL

<https://machinecatalogic.com/tadano-gr-500xl-1-rough-terrain-crane-parts-manual/>

Book No: GR-500XL-1-P3(U)-1EJ · File Pages: 404 · File Count: 1 · File Language: English