SECTION A: MAIN LOADER COMPONENTS

INTRODUCTION . . . 1
MAINFRAME 2044 Models . . . 2
MAINFRAME 2054 Models . . . 5
WHEEL DRIVES Chain Drive - 2044 Models . . . 8
WHEEL DRIVES Chain Drive - 2054 Models . . . 10
WHEEL DRIVES Axle and Housing - 2054 Models . . . 12
ENGINE AND ENGINE CONTROLS . . . 14
FUEL SYSTEM . . . 17
AIR CLEANER AND MUFFLER/EXHAUST . . . 19
WATER BOTTLE . . . 21
COOLER WATER SYSTEM Oil Cooler Assembly . . . 23
COOLER WATER SYSTEM Radiator Support . . . 26
COOLER WATER SYSTEM Radiator Assembly . . . 28
BRAKE SYSTEM 2044 . . . 30
BRAKE SYSTEM 2054 . . . 32
HYDROSTATIC MOUNT AND LINKAGE 2044 . . . 34
HYDROSTATIC MOUNT AND LINKAGE 2054 . . . 37
HYDROSTATIC MOUNT AND LINKAGE Neutral Centering Device . . . 40
HYDROSTATIC PLUMBING 2044 Models . . . 42
HYDROSTATIC PLUMBING 2054 Models . . . 46
HYDROSTATIC PLUMBING Road Homologation (IMER) - Hydraulic Brakes - 2044 Models . . . 50
HYDROSTATIC PLUMBING Road Homologation (IMER) Manual Brake Release - 2054 Models . . . 52
HYDROSTATIC PLUMBING Road Homologation (IMER) Manual Brakes - 2054 Models . . . 54
CHARGE, COOLER AND RETURN FILTER PLUMBING 2044 . . . 57
CHARGE, COOLER AND RETURN FILTER PLUMBING 2054 . . . 61
AUXILIARY CIRCUIT PLUMBING 2044 . . . 65
AUXILIARY CIRCUIT PLUMBING 2054 . . . 68
TILT CIRCUIT PLUMBING 2044 Models . . . 71
TILT CIRCUIT PLUMBING 2054 Models . . . 74
LIFT CIRCUIT PLUMBING 2044 . . . 78
LIFT CIRCUIT PLUMBING 2054 . . . 81
HIGH-FLOW PLUMBING Chassis - 2054 High-Flow Models . . . 84
HIGH-FLOW PLUMBING Lift Arm - 2054 High-Flow Models . . . 87
SELF-LEVELING VALVE PLUMBING . . . 89
FOOT PEDAL CONTROL AND CABIN PANEL . . . 91
STEERING CONTROLS Dual Lever Steering . . . 94
STEERING CONTROLS T-Bar Steering . . . 97
LIFT ARM 2044 Models . . . 99
LIFT ARM 2054 Models . . . 101
ATTACHMENT SYSTEM . . . 103
ROPS/FOPS . . . 105
SEAT, SEAT MOUNTING AND RESTRAINT BAR . . . 108
SEAT, SEAT MOUNTING AND RESTRAINT BAR Restraint Bar . . . 111
REAR DOOR AND ENGINE COVER 2044 . . . 113
REAR DOOR AND ENGINE COVER 2054 . . . 116
ELECTRICAL - TAIL LIGHTS Rear Work Light . . . 119
ELECTRICAL - TAIL LIGHTS . . . 121
ELECTRICAL - BRAKES Road Homologation (IMER) - Brake Switches - Models 2044 and 2054 . . . 123
ELECTRICAL - BRAKES Road Homologation (IMER) - DC Motor - 2044 Models . . . 125
ELECTRICAL - INSTRUMENT PANEL . . . 127
ELECTRICAL - INSTRUMENT PANEL Accessory Hookup . . . 130
TIRES . . . 132
SOUND SUPPRESSION . . . 135

DECALS

DECALS GENERAL INFORMATION . . . 137
DECALS (1 of 6) . . . 138
DECALS (2 of 6) . . . 140

machinecatalogic.com

Mustang 2044 and 2054 Skid Steer Loader Parts Manual (917333)

Document type: Parts Manual (illustrated parts catalogue with part numbers)

Brand: Mustang

Models: 2044 and 2054

Machine: Skid Steer Loader

Publication No.: 917333

Serial numbers: 2044/2044EU SN 006301 and Up; 2054/2054EU SN 008901 and Up

Language: English

Main contents

- SECTION A: MAIN LOADER COMPONENTS
- INTRODUCTION
- MAINFRAME 2044 Models
- MAINFRAME 2054 Models
- WHEEL DRIVES Chain Drive - 2044 Models
- WHEEL DRIVES Chain Drive - 2054 Models
- WHEEL DRIVES Axle and Housing - 2054 Models
- ENGINE AND ENGINE CONTROLS
- FUEL SYSTEM
- AIR CLEANER AND MUFFLER/EXHAUST
- WATER BOTTLE
- COOLER WATER SYSTEM Oil Cooler Assembly
- COOLER WATER SYSTEM Radiator Support
- COOLER WATER SYSTEM Radiator Assembly
- BRAKE SYSTEM 2
- HYDROSTATIC MOUNT AND LINKAGE 2
- HYDROSTATIC MOUNT AND LINKAGE Neutral Centering Device
- HYDROSTATIC PLUMBING 2044 Models
- HYDROSTATIC PLUMBING 2054 Models
- HYDROSTATIC PLUMBING Road Homologation (IMER) - Hydraulic Brakes - 2044 Models
- HYDROSTATIC PLUMBING Road Homologation (IMER) Manual Brake Release - 2054 Models
- HYDROSTATIC PLUMBING Road Homologation (IMER) Manual Brakes - 2054 Models
- CHARGE, COOLER AND RETURN FILTER PLUMBING 2
- AUXILIARY CIRCUIT PLUMBING 2
- TILT CIRCUIT PLUMBING 2044 Models
- TILT CIRCUIT PLUMBING 2054 Models
- LIFT CIRCUIT PLUMBING 2
- HIGH-FLOW PLUMBING Chassis - 2054 High-Flow Models
- HIGH-FLOW PLUMBING Lift Arm - 2054 High-Flow Models
- SELF-LEVELING VALVE PLUMBING
- FOOT PEDAL CONTROL AND CABIN PANEL
- STEERING CONTROLS Dual Lever Steering
- STEERING CONTROLS T-Bar Steering

machinecatalogic.com

Introduction

For your safety and continued proper operation, use only genuine MUSTANG® service parts. When ordering service parts, specify the correct part number, full description, quantity required, the unit model number and serial number.

The model and serial number decal for this unit is located on the left chassis upright. “Right” and “Left” are determined from a position sitting on the seat and facing forward.

Manitou Americas, Inc. reserves the right to make changes or improvements in the design or construction of any part of the unit without incurring the obligation to install such changes on any previously delivered units.

NOTE: *Purchase equivalent, quality tires for your loader. Contact your dealer for replacement tire information.*

NOTE: *Replacement batteries are not provided by MUSTANG. For battery specifications see “Engine and Engine Controls” chapter. ALL REPLACEMENT BATTERIES MUST BE PURCHASED LOCALLY.*

Refer to the abbreviations table located on this page for the various fastener descriptions. Standard attaching hardware torque values are also provided on the inside back cover. **If a part requires lubrication or a nonstandard torque value, it will be specified behind the part number description in parenthesis.**

Items shown in the parts list that do not have part numbers are shown for reference purposes only and are NOT available for purchase.

Dimensions are in inches unless otherwise specified.

NOTE: *The following abbreviations and symbols may be used herein:*

A	Ampere
AR	As Required
ASSY	Assembly
CCA	Cold Cranking Amperage
CYL	Cylinder
FL	Flare
FOPS	Falling Object Protective Structure
FRT	Front
GA	Gauge
HEX	Hexagon
HF	High-Flow
JIC	Joint Industrial Council
kW	Kilowatt
LBS	Pounds
LT	Left
M	Metric
MM (mm)	Millimeter
NA	Naturally Aspirated
N/A	Not Applicable
NEG	Negative
NILN	Nylon Insert Lock Nut
N•m	Newton meter
NO	Number
NPT	National Pipe Thread
NSS	Not Sold Separately
OPER	Operator
PN	Part Number
POS	Positive
PSI	Pounds per Square Inch
QTY	Quantity
REF	Reference
REQD	Required
ROPS	Roll-Over Protective Structure
RPM	Revolutions Per Minute
RT	Right
SAE	Society of Automotive Engineers
SN	Serial Number
SQ	Square
ST	Straight
TURBO	Turbocharged
V	Volt


machinecatalogic.com

MUSTANG is a registered trademark of Manitou Americas, Inc.
Multi-Tach is trademark of Manitou Americas, Inc.

Main Control Valve Table	
Model	**Control Valve Part Number Used**
2044	170-34676
2054	170-34848

machinecatalogic.com


SECTION A: MAIN LOADER COMPONENTS




machinecatalog

Item	Part No.	Name	Characteristics	Qty	Superseded PartNumber	Machine applicability
37	400-32567	PLATE/THRUST		1		
38	190-32959	KIT/CYLINDER BLOCK		1		
39	220-32671	PIN/SPRING		1		
40	170-35140	VALVE PLATE/FRONT		1		
41	NSS	RING/RETAINING		1		
42	NSS	WASHER		2		
43	NSS	SPRING		1		
44	NSS	WASHER		1		
45	NSS	BLOCK/CYLINDER		1		
46	NSS	RETAINER/PIN		1		
47	NSS	PINS/HOLD DOWN SLIPPER		1		
48	NSS	GUIDE/RETAINER SLIPPER		1		
49	NSS	RETAINER/SLIPPER		1		
50	NSS	Piston		9		
51	NSS	WASHER/THRUST		1		
52	160-32907	CAP/END		1		
	198356	PIN		1		
	198357	PLUG/PIPE		1		
53	010-32434	BEARING/TAPERED ROLLER		2		
54	400-32566	WASHER/SEAL SUPPORT		1		
55	310-32671	SCREW		4		
	190-32916	KIT/SEAL OVERHAUL		1		

machinecatalogic.com



machinecatalog.com



machinecatalogic.com

Full Version Available

Mustang 2044 and 2054 Skid Steer Loader Parts Manual (917333)

Mustang 2044 and 2054 skid steer loader parts manual 917333: engine, hydrostatic, lift arm, cab, decals, kits, schematics. Instant PDF download.

VIEW THE FULL MANUAL

https://machinecatalogic.com/mustang-2044-and-2054-skid-steer-loader-parts-manual-917333/

Publication No.: 917333 · Language: English